

Tape Wallet

Materials:

Heavy-duty tape (ex. duct tape, electrical tape)

X-acto knife or box cutter

Ruler

1. Create a long sheet of tape that measures 8.5 inches by 7 inches. To do this, tear off a strip of tape at least 8.5 inches long and place it sticky side up on your working surface.
2. Begin overlapping: cut a second strip of equal length and place sticky side down half way over the first strip, leaving half of the first piece uncovered. Fold the rest of this strip facing up over the second strip.
3. Flip over the first two strips and place a third strip of the same length sticky side down, covering the remaining sticky part of the second strip. Flip the sheet again and continue extending the size of the sheet until the needed size is satisfied. Your sheet should measure 8.5 inches by 7 inches.
4. Trim the edges.
5. Fold the wallet in half lengthwise, so it's now 8.5 inches by 3.5 inches. Tape the sides to create a large pocket to hold bills.
6. To create business card pockets, use the same method to create another tape sheet that measures 4 inches by 3.5 inches.
7. Fold about 1.5 inches over. Tape the edges of the pockets and then tape the whole piece to the large pocket. You can repeat this process to make another pocket.
8. There are infinite ways to personalize this basic design. You could add coin pockets within the larger bill pocket and place flaps on the credit card holders. You can make windows for photos or special hooks to close the wallet.

